



W1802 PARTS BREAKDOWN



W1802 PARTS LIST

REF PART # DESCRIPTION

101	X1802101	POT BOTTOM
102	X1802102	CUP
103	X1802103	FLUID TUBE
104	X1802104	COVER
105	X1802105	RUBBER WASHER
106	X1802106	LATEX JAM
107	X1802107	COMPRESSION SPRING
108	X1802108	SPRING RELIEF VALVE
109	X1802109	PAINT INLET PLUG
110	X1802110	CENTERPOST
111	X1802111	FLUID OUTLET
112	X1802112	SPECIAL NUT
113	X1802113	HANDLE
114	X1802114	REGULATOR ASSEMBLY
115	XPS17M	PHLP HD SCR M4-.7 X 6
116	X1802116	CHECK VALVE
117	X1802117	COMPRESSION SPRING
118	X1802118	SPECIAL WASHER
119	X1802119	COMBO HOSE
120	X1802120	AIR INLET PLUG
121	X1802121	BLOCK
122	X1802122	GUN BODY
123	X1802123	DIRECTION PIPE
124	X1802124	FLUID ADJ. NEEDLE
125	X1802125	SPECIAL WASHER

REF PART # DESCRIPTION

126	X1802126	FLUID CONTROL SCREW
127	X1802127	FLUID ADJ. SCREW
128	X1802128	PATTERN ADJ. SCREW
129	X1802129	O-RING 2.5 X 2.1
130	X1802130	PATTERN ADJ. KNOB
131	X1802131	SNAP RETAINER
132	X1802132	PATTERN ADJ. NEEDLE
133	X1802133	TRIGGER PIN
134	X1802134	TRIGGER
135	X1802135	SNAP RETAINER
136	X1802136	CONNECT SCREW
137	X1802137	SPECIAL WASHER
138	X1802138	HEAD
139	X1802139	FLUID NOZZLE
140	X1802140	AIR CAP
141	X1802141	DIRECTION SCREW
142	X1802142	SWITCH SPRING
143	X1802143	SWITCH PIPE
144	X1802144	SEALING WASHER
145	X1802145	SWITCH SEAT
146	X1802146	SPECIAL WASHER
147	X1802147	SPECIAL NUT
148	X1802148	BRUSH
149	X1802149	SERVICE WRENCH